



DIESEL PERFORMANCE SPECIALISTS, INC.

Phone 616.260.1396 Fax 775.205.3888

7211 CENTERLINE RD. SARANAC, MI 48881

www.dps-performance.com

Copyright© 2003 Diesel Performance Specialists, Inc.

FULL PILLAR A-PILLAR GAUGE MOUNT

** Always wear safety glasses

1. These instructions are for installation of your new Full Pillar over the A-pillar trim piece
2. Remove the A-Pillar trim piece. (It may be necessary to permanently remove and had strap on the A-Pillar trim). Remove the A-Pillar trim piece by starting at the top and gently pulling back, and to the right. When you find the top spring-clip, use a flat-blade screwdriver to press in on the clip, to get it to release. Use the same procedure for the rest of the spring-clips. Once the pillar is free from all the clips, tip the top half towards the steering wheel and lift straight up. You may need to use a little force, but don't apply so much that you break the trim piece.
3. Place Full Pillar pod in mounting position on the A-pillar trim piece. Inspect fit to see if some trimming is necessary for good fit.
4. (optional) Paint the pod with a paint that is safe for plastic.
5. With gauge pod in mounting position on the trim piece, drill a 5/32" hole near each of the four corners of the gauge pod on the flat surface area. Make sure the holes go through both the gauge pod and the A-pillar.
6. Next, drill from the side of the factory trim piece that faced, or was against the pillar. For each of the gauge mounting holes, you will drill (1) 3/8" or larger hole to run the wires and connectors through. **BEFORE YOU DRILL**, make sure that you DO NOT drill through the new gauge pod, but ONLY through the factory trim piece. Also make sure that you do not drill out any of the spring clips on the factory A-Pillar piece.
7. Place the gauge pod in position on the A-pillar and carefully run the wires for the gauge through the holes you made in the A-pillar. **NOTE**—Make sure to leave enough wire behind the gauges so you can remove them later to change bulbs, etc.
8. Install the gauges in the new pillar mount, connect the wires.
9. Fit the new pillar mount over the A-pillar and install the existing push-pins through the small holes you drilled to secure the mount.
10. Re-install the A-pillar in the vehicle.